



10 Steps Lighting Control's Panic Chart


Step 1: Ensure your Lighting Console is switched **ON**





Step 2: Check that the Lighting Consoles **Grandmaster Fader** is at **100%**




Step 3: Make sure that the **Black Out Button** is **deactivated**



Step 4: Make sure the **Lighting Console** is **not in the Blind Mode**




Step 5: Check that the **DMX cable** is **Connected into the Console**, unplug and reconnect again




10 Steps Lighting Control's Panic Chart

Step 6: Check that the DMX Splitters and Wireless DMX receiver and transmitters are **ON** and **Connected**




Step 7: Check that the **DMX cable to the Dimmers** are **connected** (unplug and reconnect)



Step 8: Check that the **Dimmers** are **turned ON**, if there is power to the Dimmers, **do this ONLY if you are authorised to do it, AS THE DIMMERS COULD BE FAULTY AND ARE SHUT DOWN OR PEOPLE ARE WORKING ON THE DIMMERS**



Step 9: Check that the **MCB (Miniature Circuit Breakers)** are turned ON, there is power to the Dimmers, **do this ONLY if you are authorised to do it, AS THE DIMMERS COULD BE FAULTY AND ARE SHUT DOWN OR PEOPLE ARE WORKING ON THE DIMMERS**



Step 10: If all the above fails, Contact: **Lighting Controls Pte Ltd**,
Tel: **+65-6846 7959**, for assistance

Lighting 
Controls 